


Operating Instructions

for Aerial Work Platform

LEO 23 GT

Machine no. 140671



Technical specifications are subject to change without notification

TEUPEN Maschinenbaugesellschaft mbH

Place of business: Marie-Curie-Strasse 13 - D 48599 Gronau - Telephone 02562 / 8161-0 - Telefax 02562 / 8161-888

Postal address: Postfach 1951 - D 48580 Gronau Internet: <http://www.teupen.info> - E-mail: mail@teupen.info

Copyright!

The copyright relating to these operating instructions remains with

TEUPEN Maschinenbaugesellschaft mbH

These operating instructions are intended for use by the owner of the machine and their staff only.

The owner of the machine may copy these operating instructions for internal purposes only.

11.04.08 TEUPEN Maschinenbaugesellschaft mbH

Contents

1. Introduction	Page 5-6
1.1 Proper use	Page 6
1.2 Explanation of symbols used	Page 7
2. Safety instructions and warnings	Page 8-12
3. Particular features	Page 13-14
3.1 Technical data	Page 15-18
3.2 Position of control elements	Page 19-21
4. Electrical power supply	Page 22-24
5. The hydr. rubber chain running gear	Page 25-26
5.1 Driving by means of the hydr. rubber chain drive	Page 27
5.2 Adjusting the height of the chain running gears	Page 28-29

6. The support system	Page 30-31
6.1 Bringing the machine in working position	Page 32
6.2 Bringing the machine in transport position	Page 33
7. Operation of aerial work platform	Page 34-35
7.1 Ground control	Page 36-37
7.2 Emergency control platform/chassis	Page 38-39
8. General maintenance instructions	Page 40
8.1 Lubrication plan	Page 40-41
8.2 Oil recommendation	Page 42-43
8.3 Oil levels	Page 44-45
8.4 Maintenance instructions for live ring, general	Page 46-49
9. Faults, causes and repair	Page 50-55
10. Disposal	Page 56

1. Introduction

The purpose of these operating instructions is to provide the owner of the Aerial Work Platform with information on the correct handling, use and maintenance of the machine. In order to ensure a proper and safe operation of the aerial work platform, please read these operating instructions carefully and follow the instructions given in these operating instructions strictly.

These operating instructions contain important information on how to operate the aerial work platform in a safe, proper and efficient manner. Comply with these instructions strictly to avoid hazards, reduce repair costs and downtimes and to increase the service life of the aerial work platform.

This aerial work platform complies with „BGG 945“ of the "Hauptverband der gewerblichen Berufsgenossenschaften" and is manufactured in accordance with EN 280 "Mobile Elevation Platforms - Design Calculations and Stability Criteria".

In the case of plants which must be approved by official authorities, the owner must have the machine inspected by accredited inspection authorities (TÜV/DEKRA) or authorized persons prior to first commissioning as well as at the specified inspection intervals.

Other national or international standards are not applied. Inspections according to other standards must be carried out separately.

In case structural or other modifications are carried out at the machine without the manufacturer's express approval, the EU Declaration of Conformity shall become invalid.

1.1 Proper Use:

The machine may only be used for the transport of persons and tools (up to the permissible carrying capacity) to enable work at aerial locations (see technical data sheet). Any other use exceeding the scope of use mentioned above shall be considered as an improper use. **Teupen Maschinenbau GmbH** shall not be held liable for any damage resulting from such an improper use.

Proper use also includes in particular

- the compliance with all information given in the operating instructions
- the proper performance of the specified inspection and maintenance work

As we do our best to always keep our product up to date, we reserve the right to modify and upgrade our aerial work platforms at any time without notification.

1.2 Symbols Used:

Two symbols are used in these operating instructions for highlighting important information:



Warning This symbol indicates information the non-compliance with which may result in serious injuries or even death.



CAUTION This symbol indicates information, the non-compliance with which may result in the machine being damaged

Fig. 1

2. Safety Instructions and Warnings!

The machine is produced according to the state of the art and the generally recognized safety regulations. However, the use of the machine involves certain hazards which may result in serious injuries or even death as well as material damage of the machine or other property. The machine may only be used

- for the specified purpose
- when it is in a perfect technical condition, in particular as regards the safety equipment.

Any defects affecting the safety must be repaired immediately.

Before commissioning the aerial work platform, please read these operating instructions carefully and comply with the following safety instructions and warnings. Any non-compliance with these instructions and warnings may result in serious personal and material damage.

In addition to these operating instructions, also comply with the enclosed operating and maintenance instructions of the manufacturers of the motor and the chain running gear.



Safety devices, e.g. limit switches, must not be made ineffective.



Screwed joints marked yellow and limit switch fixtures must not be loosened.



The valve settings may only be modified by qualified staff.

Any non-compliance will result in the warranty becoming null and void.





Fig. 2


If the machine is used transverse to a slope, nobody may stay downhill of the aerial work platform. It is also dangerous to stay downhill behind the aerial work platform while the machine is moving uphill.

In order to prevent the aerial work platform from falling over, it is necessary to let down the support until they almost touch the ground.





Note
minimum age!



**Maximum side
force 400 N**



Do not climb on the
cage railings!




No **vibrations** or **jerky
movements!**


Fig. 3




High Voltage!
Danger!



Immediately stop using the aerial work platform if the wind speed exceeds **12,5 m /sec (wind force 6)**!



Note **the flowing traffic!**
Secure parts projecting in the traffic area!



The machine must not be used as a **crane, hoist** or **lateral pull!**

Fig. 4

3. Particular Features of the Aerial Work Platform


LEO 23 GT

- Continuous proportional controls.
- Upper and lower arm telescopeable.
- Driven via diesel engine or battery
- Starting/stopping the diesel engine is possible from the platform.
- Sensitive electro-hydraulic distance control for chassis to enable exact positioning.
- Width and height of chain running gear adjustable.
- Narrow support on one side and narrow support on both sides.
- Fuzzy control
- Parallel guiding of the work cage by hydrostatic compensation system.
- 180°-turning work cage.
- Eccentrically suspended work cage has the effect of an accessible cage arm.

- Ergonomically shaped work cage with access opening.
- Installation monitoring.
- Covers above electric case and bottom control panel.
- Start support transport position lower arm (prevents incorrect landing of the lower arm in transport position).

3.1 Technical Data**LEO 23 GT**

Working height:	approx. 23.00 m
Platform height:	approx. 21.00 m
Lateral reach at 200 kg:	approx. 11.20 m
Cage load:	max. 200 kg
Size of cage (lxwxh):	1.40 x 0.70 x 1.10 m
Turning cage:	180°
Length:	min. 6.20 m
Minimum passage width:	min. 0.98 m
Height:	min. 1.98 m
Dead weight:	approx. 3000 kg
Standard support area (lxw): (middle of support disk)	min. 4,10 x 4,30 m
Min. support width (middle of support disk)	min. 2,30 m
Max. support disk load per column	ca. 22,4 kN
Area load in standard work position:	ca. 1,8 kN/m ²
Turning range standard support:	ca. 360°
Limited turning range (narrow on both sides):	2 x 15°
Limited turning range (narrow on one side):	192°
Supportable up to ground slope of:	ca. 26 %
Climbing ability (in driving direction):	ca. 30 %
(transverse to driving direction):	ca. 26 %
Driving speed:	ca. 1,5 km/h
Energy supply chain:	internal



Beispiele Zugangstechnik
Korbdrehen 180° - Korbanordnung aussermittig




Fig. 5

Drive motor Kubota Z-602



Water-cooled 2-cylinder 4-stroke diesel engine	
Volumetric displacement:	599 cm ³
Max. power at 3600 min ⁻¹ :	12.5 kW (17 PS)
Fuel type:	Diesel fuel
Noise emission:	approx. 89 dB (A)

Accessories**Electric motor EBS 90 L X 4**

Rated input voltage:	230 V / 50 Hz
Power consumption:	12.9 A
Power:	2.2 kW
Additional weight:	approx. 25 kg

Alternative battery drive

Rated input voltage of battery charger:	230 V / 50 Hz
Hydraulic unit:	48 V / 6 kW
Additional weight:	approx. 180 kg

**Fig. 6**

3.2 Position of Control Elements






Control panel in work cage with control elements for platform, support and chain functions
Turn key switch on the front left of the control panel to "Platform" symbol






Ground control panel with control elements for platform, support and chain functions

Turn key switch to "I", turn key switch at work cage to "0"

Position of Control Elements

			<p>Box level for level alignment of the aerial work platform</p>
			<p>Locking mechanism for supports (wide and narrow), make sure in any case that the supports are locked correctly !</p>
			<p>Drive motor case (OPTION) (Fuel refill cutout in lid, filling level indicator on opposite side)</p>

	<p>Hydraulic tank, 230-V connection and control box</p>
	<p>Manual pumps for emergency control of platform and supports</p>
	<p>Cable remote control for chain functions with fast/slow change-over (if not used, insert jumper in any case)</p>

4. Electric Power Supply

Power is supplied either via the local mains network using an extension cable (230 V) or by the mains-independent drive motor.


As an alternative, a battery drive is also possible.

If an extension cable is used, connect the plug to the socket of the extension cable.

Length of cable :

max. 40 m with 3 x 2.5 mm²


max. 80 m with 3 x 4.0 mm²




To start the drive motor, press the pushbutton with the spiral symbol until the preheating indicator (yellow spiral symbol) goes out (comply with operating instructions of engine manufacturer!)

Start power supply by drive engine:

- Start of drive engine at electric control box or in work cage
- Turn key switch to the right until the engine starts





Avoid unnecessary starting: Voltage drop of starter battery



Stop power supply by drive engine:

- Stop of drive engine at electric control box or in work cage,
- Turn key switch to the left until the drive engine stops



48-V battery drive:

If the machine is equipped with a battery drive, the operating and maintenance instructions of the manufacturer of the battery and battery charger must also be complied with!

Continuous operation via the electric motor is not permissible (danger of overheating)

Daily charging of the batteries is recommended if the platform is battery-driven. In the case of a connection to 230 V (charger), the batteries are charged during operation. Thus the service time of the machine is increased.

Indicator lamps for battery operation:

Red lights in work cage / ground control panel flashing: battery discharged

Yellow light in ground control panel: battery mode switched on


When the red light is flashing, bring machine in transport position immediately!

Indicator lamp at battery case:

Red: battery is being charged

Green: battery full


5. The Hydraulic Rubber Chain Drive



When driving on slopes make sure that the specified slope angles are not exceeded!

Permissible slope: **transverse to driving direction max. 26 %**
in driving direction max. 30 % (26 % in battery mode)

The Hydraulic Rubber Chain Drive



The hydr. travel drive controlled via two control levers on the cable remote control which is connected to the socket outlet at the chassis by means of a bayonet catch.

By moving the two control levers forward and backward, you can achieve a very sensitive starting behavior of the two rubber chains in both directions.

By moving the two levers in opposite direction, you can achieve a turn movement at a minimum radius (on the spot if the ground is level).

5.1 Driving by means of the hydr. rubber chain drive

In order to drive through narrow aisles or doors, you can turn the work cage without having to support the aerial work platform (control element at ground control, see Chapter 3.2)



Driving by means of the rubber chain drive from the cage is only permissible up to a slope of 8° (15 %)

- Switch on power supply (see Chapter 4)
- Connect cable remote control to outlet at chassis and select the required speed(symbol "hare" or "turtle")
- Switch toggle switch on ground control panel to "chain" symbol
- Move the two levers forward or backward at the same time to obtain a **"forward/backward movement"** and select the **"speed"**
- Move the levers in opposite direction to turn the machine in the required direction
- Interrupt power supply

5.2 Adjusting the Height of the Chain Running Gears:**Caution Danger of Tilting!**

In any case, two persons are required to adjust the height of the chain running gears! Adjust the supports such that the aerial work platform cannot fall over (max. inclination 14.5°, 26 %)! When adjusting the chain running gear, always adjust the supports to wide support position

**Caution Risk of Injuries!**

With narrow-adjusted chain running gear, never loosen the locks if the aerial work platform is supported high (chain running gear shoots down)!

Procedure for pushing the chain running gears inward (narrow adjustment):

To push in the chain running gear, jack it up by means of the supports until the chain running gear has no ground contact anymore (max. 10-20 mm off the ground)



Then loosen the two locks by means of the manual pump lever (1st person).
Move up the corresponding columns carefully until the chain running gear has ground contact and is pushed in (2nd person). When the required position is reached, allow the locks to engage again!
Important! Before subjecting the chain running gear to load, check if the locks have engaged properly. Both levers must have returned to the mark (red arrow) automatically.

Procedure for pushing the chain running gears outward (wide adjustment):



To push out the chain running gear, it must be lifted up by means of the support until the chain running gear has no ground contact anymore (max. 10-20 mm off the ground)

Then loosen the two locks by means of the manual pump lever (1st person).
Move down the corresponding columns carefully until the chain running gear loses ground contact and is pushed out (2nd person). When the required position is reached, allow the locks to engage again!

Important! Before subjecting the chain running gear to load, check if the locks have engaged properly. Both levers must have returned to the mark (red arrow) automatically.


6. The Support System

In addition to the standard support, the following support variants are available:

	<p>Narrow support on one side</p> <p>Limited turning range 192°</p>
	<p>Narrow support on both sides</p> <p>Limited turning range 2 x 15°</p>



Make sure that the ground is firm, if necessary, increase the support area by means of planks. All supports must be **loaded**, the rubber chain running gears must be free!



In order to increase the safety of the aerial work platform in slopes (skidding, stability), the ground disks must be aligned horizontally (see sketch). This is also important in view of their limited ability to adapt to the environment. Anchoring the supports by means of chains, ropes, ground anchors, etc. is not permissible.

6.1 Bringing the Machine in Working Position



-Observe the supports while they are extended and retracted

To support the machine, position the supports at the required position and lock them properly. At the ground control panel, turn the key switch to "I" and the platform function selector switch to "supports".

-Lower the supports evenly using the toggle switches and bring the aerial work platform in working position

When the supports are in place correctly, the green lamps in the control panels light up continuously.

-Bring the chassis in horizontal position by aligning the supports using the box level. The bubble of the box level must be within the 1 ° circle.

6.2 Bringing the Machine Transport Position

The upper and the lower arm must be fully retracted in the transport support!

-Switch on power supply (see Chapter 4)

At the ground control panel, turn the key switch to "I" and the platform function selector switch to "supports".

-Lower the chassis using the toggle switches and bring the front and rear supports in top position

-Loosen the locking pins of the front and rear supports, move the supports to transport position and lock them properly using the locking pins

-Interrupt power supply

7. Operation of Aerial Work Platform:

Control from work cage

To enable a perfect operation of the lifting platform, a proper working position of the machine and power supply are required.



In order to maintain a perfect function of the control elements it is absolutely necessary to protect the control panel against water, moisture, paint, etc. by means of the provided protection cover.

Procedure:

- Turn key switch to "platform" symbol
- Lift up telescope from transport support

The function "extend lower arm" is only possible if the lower arm is lifted up completely. To extend the lower arm, keep actuated the lower arm control element (switch-over is effected automatically after approx. 10 sec.)

- Control the aerial work platform by means of the corresponding pushbuttons and speed selector switches

In case the movement stops during a travel to the transport position, the upper arm must be lifted up first in order to turn to the transport position.

If it is positioned correctly, the green lamp is flashing quickly and you can approach the transport position (lowering).

7.1 Ground Control Panel:

-Ground control is only permissible if nobody is in the working cage

Ground control may only be used if the required accident prevention measures are taken.

The ground control enables the user to transport loads, e.g. billboards, advertising banners, light or loudspeaker equipment (up to max. permissible cage load) to certain heights.



These loads must not exceed a size of 1.4 m² and must be properly protected against falling out.

For ground control, make sure that the **work cage is unmanned** and the toggle switch on the front left of the control panel of the work cage is in position 0.

Additionally, the key switch in the ground control panel must be in position "1" (platform mode).

Now, you can position the aerial work platform as required using the corresponding pushbutton in combination with the speed controller.

7.2 Emergency Control Plat-



In emergency control mode, the upper and lower arm must be retracted completely before lowering them







-operation with the manual pump is only intended for down, retracting and rotating movements **TOWARD THE TRANSPORT POSITION**

- fix the platform-chassis valve on the valve block which is situated under the hydraulic tank on symbol "platform" and lock the power regulation valve beside the valve block


-Take the tube for the manual pump from the holder and slip it on the pinion of the manual pump (check if handwheel is)

-select the required direction by pumping and actuating the corresponding valves (marked red) at the same time

After using the emergency control, it is necessary to re-lock the valves!



**Power regulati-
on valve**




8. General maintenance instructions:

After first commissioning, aerial work platforms must be inspected by an accredited expert at intervals of one year !

8.1 Lubrication Plan

- | | | | |
|----|-------------------------------------|----|-------------------------|
| 1: | Lubrication grease Fuchs Renolit MP | | |
| 2: | Spray grease Optimol White T | 3: | Motor oil Titan 15 W 40 |

Lubrication:	all lubrication nipples	-weekly with 1
	all articulated joint and slide areas,	-depending on degree of soiling, at least monthly with 2



8.2 Recommended oil

When it leaves our workshop, the hydraulic system of this machine is filled with:

PLANTOHYD 32-S

Environmentally friendly multi-use hydraulic fluid



Mixing with hydraulic oils of other viscosity classes is not permissible for safety reasons. If, for any reason, another conventional hydraulic oil is to be used, the hydraulic oil of the complete hydraulic system must be replaced.

In this case, we recommend the hydraulic oil Renolin MR 5 or a hydraulic oil according to the following oil recommendation.

Oil Recommendation

A proper function, perfect operational safety and a long service life mainly depend on a careful selection of the hydraulic oils. For the hydraulic system, we recommend hydraulic oils which contain, in addition to the additives improving the corrosion protection and the ageing resistance and reducing the wear and tear, additives improving the stick-slip behavior, avoiding deposits and cavitation and preventing undesired reactions caused by penetrating water. The hydraulic oils listed below have been used successfully in our systems. We recommend the use of these oils or equivalent products.

Einsatztemperatur Application temperature Température d'application ISO VG				
0-30° VG 22	BP Energol HLP-D 22	HLPD-OEL 22	Renolin MR 5	Shell Hydrol DO 22

8.3 Oil Levels:

Only check the oil level of the hydraulic system and refill oil, if necessary, when the cylinders are retracted, i.e. in transport position of the machine.



Mixing of different oils is not permissible. Otherwise the whole plant may be damaged.

Only use oils according to the enclosed oil recommendation.

-Check the hydraulic oil level weekly and, if necessary, refill with Fuchs Plantohyd 32-S until oil is present in the filter insert.

Filling volume of hydraulic system:	approx. 90 l
Filling volume of hydraulic tank:	approx. 45 l
Filling level between min. and max.:	approx. 6 l

Oil level in drive engine (OPTION):

The drive engine is filled with **Engine oil Titan 15 W 40**.

-At the drive engine, check engine oil level weekly according to Kubota operating instructions

Filling volume in drive engine: see Kubota operating instructions

When oil level is low (see dipstick) refill oil according to Kubota operating instructions.

Fuel:

The drive engine is operated with diesel fuel no. 2-D (ASTM D975).

The filling level of the fuel tank is: approx. 12 l

8.4 Maintenance Instructions for Live Ring

Checking the fixing screws:



The fixing screws must be checked every 700 operating hours or every 6 months, at the latest. This period is to be adapted accordingly in the case of special operating conditions.

Check the tightening torques after the first 100 operating hours in order to compensate possible settling effects.

Retighten the screws with the following tightening torques:

Screw size:	Screw quality:	Tightening torque:
M 12	10.9	109 Nm
M 16	10.9	270 Nm



After that, retighten the screws every 700 operating hours or at shorter intervals, if required due to special operating conditions, or every six months, at the latest.

If this requirement is not met, personal and material damage may be the consequence.

Checking the screws for loosening/replacing the screws:

- Relieve the screws of any external load
- Check the tightening torque using a torque wrench and adjust it to the values listed above
- Replace loose screws

Check the tilting play:

Wear and tear in the bearing system results in a changed bearing play. For this reason, the bearing play must be checked at regular intervals.

Check the tilting play after 2000 operating hours or after 12 months, at the latest.

If this requirement is not met, personal and material damage may be the consequence.

Re-lubrication intervals:

In the case of difficult outdoor conditions, re-lubricate every 100 to 200 operating hours!

Additionally, torque bearings must be re-lubricated :

-after each cleaning, e.g. water/steam spraying etc.

-before and after extended standstill periods (e.g. inactive winter months)

General Maintenance Instructions:

-hydraulic hoses must be checked for damage and leaks at least once every month

-hydraulic hoses must be replaced completely after 6 years

-check all components visually for deformation and cracks

-check bolts and nuts regularly for tight fit

-check rubber chains for wear and tear and proper tension

check function of limit switches at chassis and check if they are clean

-each time the aerial work platform is used, it is vital that the machine be checked for proper function before the work is started

9. Faults, Causes and Repair

-no drive engine function (OPTION)	-tank empty	-refill (note fuel type!)
	-drive engine fuse defective	-replace
	-starter battery empty	-charge starter battery
-with power supply via on-site power supply station, no functions	-safety devices triggered (fuse, r.c.c.b., motor circuit breaker)	-check and switch on safety organs
	-extension cable defective	-check, replace if necessary
	-wrong cable cross-section with long extension cable	-select cable cross-section

-no function possible from ground control	key switch in work cage on "platform"	turn key switch to "0"
	- em. stop pushbutton pressed	-unlock
-no platform function possible from cage	-wrong position of switch in work cage	-switch toggle switch to "platform"
	- em. stop pushbutton pressed	-unlock
	-incorrect support	-support correctly

	-no supply voltage (possibly too low)	-check
	-r.c.c.b tripped	-switch on
-extension of upper arm not possible	-upper arm in transport support	-lift up for a short time
	-upper arm not lifted up far enough	-lift up upper arm
-lowering of upper arm not possible	-upper arm not above carriage	-turn upper arm to- ward carriage

-extension of lower arm not possible	-lower arm not erected fully	-erect completely
-lifting and lowering of "lower arm" not possible	-telescope not retracted fully	-retract completely
-slewing not possible	-upper arm telescope still in transport support	lift up telescope
-green lamp in work cage flashing	-not supported correctly	-support correctly
	-support locking devices not locked	-lock

-red light lights up continuously	-control lever actuated during the start operation	-press em. stop and start control system again
	-system error	-call service
-motor pump running and stalling	-hydraulic hose kinked	-check hoses, e.g. below chassis
	-pressure filter dirty	-open and replace filter insert
-cylinders lower automatically	-hydraulic system dirty	-shut down machine immediately -call service
-motor pump running, but no pressure in system	-hand wheel of manual pump loosened	-close hand wheel (turn clockwise)

-load motor pump noise and travel movements slow down until standstill	-too little hydraulic oil in tank	-check and, if necessary, refill hydraulic oil -note oil type
	-hydraulic plant leaking	-check and call service
-socket outlet in work cage without voltage	-mains supply interrupted	-check
	-plug not in outlet	-plug in
	-safety organs tripped	-check

10. Disposal

When it comes to final decommissioning and scrapping of the machine, it is important that all materials used be disposed of properly.

The hydraulic and motor oils as well as the hydraulic hoses used are to be disposed of by specialized companies in accordance with the local requirements.

The metals, i.e. steel and aluminum, must be supplied to the local metal disposal systems and reused, if possible.

Plastic and rubber materials (tires) are to be recycled according to the local requirements.

The operating instructions are to be supplied to the local paper disposal system.