



Here are some useful tips which may help you with Quickfencer.

Tip 1

- When netting rolls need joining don't let the roll end leave the pivot arm
- Raise the 3 point linkage and join the netting within the pivot arm
- This is easier than working on the ground

Tip 2

To load big rolls without using Quickfencer sleeves:-

- With the roll on its side thread a sling through the roll centre
- Insert a 600mm x 20mm steel bar through the sling bottom
- Raise the sling and roll using appropriate loader
- Before lowering onto Quickfencer post :
- Place a cut off wooden block on the ground next to the Quickfencer post
- This prevents the roll from touching the Quickfencer deck when loaded
- The steel bar can then be safely removed and the sling taken away
- The Quickfencer and the loaded rolls can then be raised by the 3 point linkage
- The big roll then settles on the Quickfencer deck and the wood block can be removed

Tip 3

To Tie off at strainers method 1:

- Use the normal method of paying out and tensioning the netting
- Place an angle iron over the netting against the post
- Coach bolt the angle iron to the post thus gripping the tensioned netting
- Cut off enough netting and tie off to the strainer
- Remove the coach bolts and angle iron

Tip 4

To tie off at strainers method 2:

- Use the patented Quick Clamp
- Stop short of straining post
- Clamp the netting with the Quick Clamp
- Tension the wire
- Cut off leaving enough length to tie off to strainer
- Tie off to strainer
- Remove Quick Clamp